

## Alo Tech M-1 - QUICK GUIDE

Thank you for buying this hands free Alo yes Life 01 device. This device allows you to receive calls, listen to music, etc. while driving or practising your favourite sport.

This is a quick user's guide, for more information as well as a detailed manual, we recommend you visit our website:

The packaging must contain the following articles. If this is not the case please contact the shop where you bought this product:

- Alo Tech M-1 device
- USB - Micro-USB Charging cable
- Spare mic foam
- Velcro
- Instruction Manual

The Alo Tech M-1 device has just one button (a) to enable a simple yet effective use, it also has a LED status light (b) located close to the microphone which will help you configure and use the device.

### **TO CHARGE THE BATTERY**

Charge the battery before using it for the first time and when you have not used it for a long time.

In order to charge the device, connect the micro-USB connector of the cable provided (c) to the connector that is situated in the lower part of the microphone (d) and the other end of the cable to a USB port of a computer, a car charger or a wall charger.

Once the device is charged, the red status light will turn off.

### **INSTALLATION**

The Alo Tech M-1 device must be installed as close as possible to your ear in order to guarantee optimal sound quality.

The device can be positioned on top of the side fabric of the helmet, with the help of the Velcro strips provided, or can be placed under the side fabric and / or sponge of the helmet. Bear in mind that if the sponge or fabric is very thick both the quality as well as the power of the sound can be affected.

The microphone must be placed in a central position close to your mouth.

## **USE**

### **TO TURN ON AND OFF**

To turn the Alo Tech M-1 device on press the button (a) until the LED light (b) flashes blue, an acoustic sound will indicate that the device has been switched on.

To turn the device off press the button (a) until the LED light (b) flashes red just once, an acoustic sound will indicate that the device has been switched off.

### **Pairing a Bluetooth® device**

With the Alo Tech M-1 device switched off, press and hold the button (a) until the LED light (b) flashes red and blue alternately. Set your Bluetooth® device to search mode and select the device *aloTechM-1*, if necessary introduce the code 0000.

### **Pairing an Alo Tech M-2 with the INTERCOM function**

Turn off the first paired device. With the Alo Tech M-1 device switched off, press and hold the button (a) until the LED light (b) flashes red and blue alternately. With the Alo Tech M-2 device switched off, press and hold the button (a) until the LED light (b) flashes red and blue alternately to set it in search mode. PRESS THE CONTROL BUTTON (a) ONLY ONCE. IN A FEW SECONDS THEY WILL BE LINKED.

We recommend that you turn the device off and on again after this second link.

## **Call functions**

### **Answering, ending and rejecting calls**

When you receive a call, the Alo Tech M-1 device will emit an acoustic sound, you can respond to the call with a simple "alo" into the microphone, the device has the voice answer feature integrated into it, independent of your telephone. You can also answer the call by pressing the button (a).

To end the call press the button (a) or wait until the person you are talking with hangs up.

To reject a call, press the button (a) twice when you have an incoming call.

### **To make calls**

To make calls press the button (a) once in order to activate the voice dialling of your telephone (your telephone must have a voice dialling function and must be activated)

To redial the number, press the button (a) twice.

### **Volume adjustment**

In the functions of calling, listening to music and spoken orders from a GPS device, the volume is controlled from the transmitting apparatus (mobile telephone, MP3, GPS, etc.)

### **Security recommendations**

Configure, turn on and off the device when you are stationary.

Do not listen to music while driving as it could distract your attention.

Adjust the volume in such a way as to be able to hear background noises, both when driving as when practising outdoor sports.

Do not disconnect the charging cable by pulling it.

### **Guarantee**

This product comes with a 24 month guarantee under applicable law. Should you need to use the guarantee, it must be provided together with the original receipt, issued by an official distributor and showing the date of purchase.

The guarantee does not cover defects caused by misuse, accidents or tampering with the device.